



Iron-On Patch Application Instructions

* Use Lowest Heat Setting *

1. Place patch on desired area with backside down.
2. Using a hard, flat surface such as a wooden cutting board, iron the design on a cotton setting. Use the lowest heat setting possible and press and hold approx. 30-60 seconds.

Heavier fabrics may require more time, lighter fabrics less time. **Do not use steam setting. Remove water from iron. Caution !!! High heat settings can melt the patch.**

3. After heat is applied, transfer should be permanently sealed onto fabric. If not, reapply heat for an additional 20-30 seconds. Allow to cool.

4. Turn garment inside out and apply heat to back of design area for approx. 20 seconds.

* Please make sure you are not attaching the patches to leather, polyester or any other material that may be destroyed by high temperatures.